

SW4 IS MOUNTED ON FRONT PANEL
AND MUST BE WIRED TO J1.
5" LONG CABLE

SW4

1 2 4 8 C

J2

FOR ASSEMBLY: INSTALL AND SOLDER PINS (PIN MILL-MAX 0552-1-15-15-11-27-10-0)
THEN PLUG BOARD (PIN G-LINK BOARD #1) INTO SOCKETS.

J3

FOR ASSEMBLY: INSTALL AND SOLDER PINS (PIN MILL-MAX 0552-1-15-15-11-27-10-0)
THEN PLUG BOARD (PIN G-LINK BOARD #1) INTO SOCKETS.

U9

ASSEMBLE AVAGO PN AFBR-57M5APZ INTO
FINISTAR PN V2838-95-N1 SFP CAGE WITH
MOLEX PN 74441-0001.
THE ENTIRE ASSEMBLY IS NOT WASHABLE.

U16

ASSEMBLE AVAGO PN AFBR-57M5APZ INTO
FINISTAR PN V2838-95-N1 SFP CAGE WITH
MOLEX PN 74441-0001.
THE ENTIRE ASSEMBLY IS NOT WASHABLE.

DS6

DS7

DS8

SW3 IS MOUNTED ON FRONT PANEL
AND MUST BE WIRED TO J7.
2" LONG CABLE

SW3

C 1 2 4 8

J6

1 2 4 8 C

SW2

SW1

FOR ASSEMBLY: INSTALL AND SOLDER PINS (PIN MILL-MAX 0552-1-15-15-11-27-10-0)
THEN PLUG BOARD (G-LINK BOARD #1) INTO SOCKETS.

FEM INTERFACE BOARD (DWG# 126Y-267977 REV A) ASSEMBLY TOP

pin 1 of RS232
connector

