## **PHENIX**

# PRPOSED DESIGN CHANGES FOR THE NORTH ARM MUON HIGH VOLTAGE DISTRIBUTION SYSTEM

This report shows the proposed design of the North Arm HV Distribution System. The design is based on the lessons learned in the design and implementation of the South Arm system.

Gregory W Hart

Los Alamos National Laboratory, P-25

31 July 2001

## **Table of Contents**

Cover Page	Page 1
Table of Contents	Pages 2-3
Technical Details	Page 4
South Arm System Drawings (Typical Octant)	
HV Coax Cable (Distribution Box to Power Supply Filter-Plug box	
Assembly Drawing	Page 5
LeCroy HV Plug/Filter Box	
Schematic	Page 6
PCB Layer 1	Page 7
PCB Layer 2	Page 8
PCB Fabrication Drawing	Page 9
Box Fabrication Drawing	Page 10
PCB Assembly Drawing	Page 11
Assembly Drawing Cables-Box	Page 12
Distribution Boxes, Mechanical details	Do 22 12
St 1, Board Assembly Drawing	Page 13
St 1, Gaps 1 & 2 Box Assembly	Page 14
St 1, Box Fabrication Distribution Poyes, Schematics	Page 15
Distribution Boxes, Schematics	Dogg 16
St 1, Octant 1, Gaps 1-2 Station 1 South Block Diagram	Page 16 Page 17
Station 1 South Block Diagram Specification / Data sheets	Page 17
(www link addresses)	rage 10
(WWW IMME addresses)	
<b>North Arm System Drawings (Typical Octant)</b>	
Chamber Mounted Connector	Page 19
CH-DB Cable	
(Chamber to Distribution Box)	
Sh 1, Assy Dwg & Sch.	Page 20
Sh 2, Cable End Detail	Page 21
Sh 3, Labels & Lengths	Page 22
DB-PS Cable	
(Distribution Box to Power Supply)	
Sh 1, Assy Dwg & Sch.	Page 23
Sh 2, Cable End Detail	Page 24
Sh 3, Labels & Lengths	Page 25
Distribution Boxes	
(Mechanical details)	
Sh 1, St 1, Front Panel Silk	Page 26

Sh 2, St 1, Front Panel Fab	Page 27
Sh 3, St 1, Front Panel Assy	Page 28
Sh 1, St 1, Rear Panel Silk	Page 29
Sh 2, St 1, Rear Panel Fab	Page 30
Sh 3, St 1, Rear Panel Assy	Page 31
Sh 1, St 1, Bot. Panel Fab	Page 32
Sh 2, St 1, Bot. Panel Asy	Page 33
St 1 Panel to PCB Wire Assy	Page 34
HV Board, Layer 2	Page 35
HV Board, Fab Dwg.	Page 36
HV Board, Silkscreen	Page 37
HV Board, Soldermask	Page 38
HV Board, Assembly Dwg.	Page 39
North Arm HV Distribution System	
Block Diagram Schematic	Page 40
St 1, Sheet 1 (Oct 1, 2) Schematic	Page 41
Specification / Data sheets	Pages 42-43
(www link addresses)	
General Wire Products, 11 cond.	Page 44
cable data sheet	

#### **Technical details**

For the South Arm chambers, we installed a plastic utility box near the chambers. A circuit card(s) with screw terminals and bleeder resistors was installed inside the box. The twisted wires from the chamber cards entered the box on one side through a conduit coupler. The HV inputs to the box are a bundle of red coaxial cables (RG-59) that enter the box through a larger conduit coupler on the adjacent side of the box.

We found that it was difficult to connect the wires and cables inside the box, and that access to the box would be limited. For the North arm, we plan to use a high voltage, multi-pin plug and socket interface at the chambers, and move the bleeders and terminals to a large chassis located near the power supplies.

We will replace the coaxial cables with multi-conductor high voltage, shielded cable.

For the South Arm, the end of the bundle of eight coax cables is soldered to a PCB mounted inside a small plastic box. This PCB contains a filter network. The opposite side of this box holds the mating AMP LHV Plug connector. These connectors plug into the HV Power Supply (HVPS). During installation we discovered that the density at the high voltage panel is very tight, making installation and strain relief difficult.


For the North Arm, we will move the filter network to a circuit card inside the rack-mounted chassis. We will use a multi-conductor high voltage cable from the chassis to the power supplies, which will decrease the front panel density and should improve the ability to strain relieve these connectors.


The High Voltage Multi-Pin connectors are made by AMP Inc., a subdivision of Tyco Electronics. They are rated at 2500 VDC. These connectors are referred to as "M Series Special Applications Connectors". They are used by CAEN, a high voltage power supply manufacturer, in their model 1526 High Voltage board. These connectors are also used in the LeCroy Model 1440 High Voltage Power Supply.


I have tested these connectors, with pins in adjacent holes for 7 days at 5,000 volts DC with no detectable leakage current.


The HV Distribution Box will be installed in the racks next to the HV Power Supplies on the elevated platform. A plug-in HV Distribution/filter circuit PCB has been designed for 16 channels. These cards are designed to operate with adjacent channels at 3,500 volts, in the event a wire breaks in the chambers.


The 11 wire multi-conductor, high voltage shielded cable is based on the 19 wire cable is used a Jefferson Labs. The wires within the shield are Teflon insulated, with a rating of 10 KV DC. The outer jacket is red in color, and rated for plenum use, UL Subjects 13, 910 and 1581.





















				В	С			D			
ITEM REF #	QTY	MANUFACT	JRER	DESCRIPTION		PART #		Source	Cat	# Cos	st/ea
	1	Weidmuller-k	Klippon	Box, Polyester, UL94V-0, Black		951024		Newark/Farnell	561-5	599 38	3.00
TS16- TS18	3	Weidmuller-k	Klippon	Terminal Block, 45 deg Clamp, 10	position	3026-6		Newark	90F91	76 1.	.03
TS1-6, TS13-15	9	Weidmuller-k	Klippon	Terminal Block, 45 deg Clamp, 4 p	position	3077-6		Newark	90F91		.03
R13-24	12	Multicomp		Resistor, Carbon Comp., 1W 1K oh	m, +/-10% tol, 500V	RC100G4R7K	3	Newark	92N35	21	.72
R1-12	12	Victoreen		Resistor, 250 Gohms, Epoxy Coate	d, 5Kv, 1 W, 10% tol	MOX-750-23	250,000 Meg 10%	Harrison		4.	.11
J1-3	3	BERG		Header, Vertical, Double Row, Gold	Plated, 8 pins	67996-272		Newark	89F621	9	32
	12	BERG		Jumper socket, gold plated, open	top, Blue	65474-001		Newark	94F734	.4	.35
	1			PCB		63Y 299047					
				*						•	

Place shorting plugs on J1- J3 on left pins only





PC Card Assembly Notes


- 1 .Assemble and solder per IPC -6012 Class II
- 2. Apply acrylic conformal coating on all exposed solder joints on bottom side of card and on R1-R12 on top side
- 3. Do not install TS7 thru TS12


Board Assembly Drawing

	Los Alamo	s Nationa	I Labora	tory	
Title	MUON TR	MUON TRACKING HV DIST. SYSTEM			
	STATION   SOUTH				
Size	Date Originate	ate Originated: 25 FEB 1998			
C	Date Last Rev	ised: 12 June	2000		
LANL D	WG # 63Y2990	047S1A	Approved By	r: W. Sondheim	
PHENIX	DWG #:105-03	12-0221	Drawn by: G	. Hart , P-25	
Filenan	ne 299047S1. <sub> </sub>	pcb	Sheet	of	









## South Arm HVDS Components

#### Wire / Cable

Technical data sheet RG 59/U Coax

http://www.colemancable.com/catalog/92004.pdf

Technical data sheet Belden, 83003 wire

http://ecom.belden.com/static/ZZBLDNTD01FROMCATA.HTM?P0=83003

Technical data sheet Judd, 5KV wire

http://www.juddwire.com/jwelcome.nsf/flexrad hv.htm

#### Hardware

Drawing of Data of Weidmuller enclosure

http://catalog.weidmuller.com/asp/datasheet.asp?PN=951024&FAM=Boxes

Drawing & Data of MK Term Blocks

http://www.newark.com/product-details/text/cd119/5249.html

Drawing & Data of Bud plastic box

http://www.budind.com/pdf/hb789.pdf

#### **Electronic Components**

Drawing & Data of 30GAD10 Capacitor


http://www.newark.com/product-details/text/cd119/7173.html


Drawing & Data of 1 Watt Resistors


http://www.newark.com/product-details/datasheet/spc/ta-84.pdf

Drawing & Data of MOX HV Resistors

http://www.ohmite.com/catalog/pdf/v minimox.pdf







A	В	c	D
Cable Label	Length	Cable Label	Length
ST 1 OC 1 GAP 1	69 M (226 Ft)	ST 2 OC 1 GAP 1	87.9 M (288 Ft)
ST 1 OC 1 GAP 2	69 M (226 Ft)	ST 2 OC 1 GAP 2	87.9 M (288 Ft)
ST 1 OC 1 GAP 3	69 M (226 Ft)	ST 2 OC 1 GAP 3	87.9 M (288 Ft)
ST 1 OC 2 GAP 1	69 M (226 Ft)	ST 2 OC 2 GAP 1	75.9 M (249 Ft)
ST 1 OC 2 GAP 2	69 M (226 Ft)	ST 2 OC 2 GAP 2	75.9 M (249 Ft)
ST 1 OC 2 GAP 3	69 M (226 Ft)	ST 2 OC 2 GAP 3	75.9 M (249 Ft)
ST 1 OC 3 GAP 1	69 M (226 Ft)	ST 2 OC 3 GAP 1	60.9 M (200 Ft)
ST 1 OC 3 GAP 2	69 M (226 Ft)	ST 2 OC 3 GAP 2	60.9 M (200 Ft)
ST 1 OC 3 GAP 3	69 M (226 Ft)	ST 2 OC 3 GAP 3	60.9 M (200 Ft)
ST 1 OC 4 GAP 1	69 M (226 Ft)	ST 2 OC 4 GAP 1	48.9 M (160 Ft)
ST 1 OC 4 GAP 2	69 M (226 Ft)	ST 2 OC 4 GAP 2	48.9 M (160 Ft)
ST 1 OC 4 GAP 3	69 M (226 Ft)	ST 2 OC 4 GAP 3	48.9 M (160 Ft)
ST 1 OC 5 GAP 1	69 M (226 Ft)	ST 2 OC 5 GAP 1	36.9 M (121 Ft)
ST 1 OC 5 GAP 2	69 M (226 Ft)	ST 2 OC 5 GAP 2	36.9 M (121 Ft)
ST 1 OC 5 GAP 3	69 M (226 Ft)	ST 2 OC 5 GAP 3	36.9 M (121 Ft)
ST 1 OC 6 GAP 1	69 M (226 Ft)	ST 2 OC 6 GAP 1	39.9 M (131 Ft)
ST 1 OC 6 GAP 2	69 M (226 Ft)	ST 2 OC 6 GAP 2	39.9 M (131 Ft)
ST 1 OC 6 GAP 3	69 M (226 Ft)	ST 2 OC 6 GAP 3	39.9 M (131 Ft)
ST 1 OC 7 GAP 1	69 M (226 Ft)	ST 2 OC 7 GAP 1	51.9 M (170 Ft)
ST 1 OC 7 GAP 2	69 M (226 Ft)	ST 2 OC 7 GAP 2	51.9 M (170 Ft)
ST 1 OC 7 GAP 3	69 M (226 Ft)	ST 2 OC 7 GAP 3	51.9 M (170 Ft)
ST 1 OC 8 GAP 1	69 M (226 Ft)	ST 2 OC 8 GAP 1	102.9 M (338 Ft)
ST 1 OC 8 GAP 2	69 M (226 Ft)	ST 2 OC 8 GAP 2	102.9 M (338 Ft)
<sup>3</sup> ST 1 OC 8 GAP 3	69 M (226 Ft)	ST 2 OC 8 GAP 3	102.9 M (338 Ft)

· · ·
Length
56.6 M (186 Ft)
56.6 M (186 Ft)
48.6 M (159 Ft)
48.6 M (159 Ft)
38.6 M (127 Ft)
38.6 M (127 Ft)
30.6 M (100 Ft)
30.6 M (100 Ft)
22.6 M (74 Ft)
22.6 M (74 Ft)
24.6 M (81 Ft)
24.6 M (81 Ft)
32.6 M (107 Ft)
32.6 M (107 Ft)
66.6 M (219 Ft)
66.6 M (219 Ft)


Each cable will have two Labels, one on each end.


Location shown on Sheet 1 Total number of cables = 64

## ASSEMBLY DRAWING

Labels & Cable Lengths

		201191110			
	Los Alamos Nationa	l Laboratory			
Title	Title MUON TRACKING HV DIST. SYSTEM				
	HV Cable, Chamber to HV	Distribution Box			
Size	Date Originated: 31 May 2001				
C	C Date Last Revised: 7 June 2001				
LANL DWG	LANL DWG # 135Y299083 Approved By: W. Sondheim				
PHENIX D	NG #: 002-0312-226	Drawn by: G. Hart			
Filename	135Y299083 CH-DB-1.pcb	Sheet 3 of 3			





Cable Label	Length
ST 1 OC 1 GAP 1	2 M (80 in)
ST 1 OC 1 GAP 2	2 M (80 in)
ST 1 OC 1 GAP 3	2 M (80 in)
ST 1 OC 2 GAP 1	2 M (80 in)
ST 1 OC 2 GAP 2	2 M (80 in) 2 M (80 in)
ST 1 OC 2 GAP 3	2 M (80 in)
ST 1 OC 3 GAP 1	2 M (80 in)
ST 1 OC 3 GAP 2	2 M (80 in) 2 M (80 in)
ST 1 OC 3 GAP 3	2 M (80 in)
ST 1 OC 4 GAP 1 ST 1 OC 4 GAP 2 ST 1 OC 4 GAP 3	2 M (80 in) 2 M (80 in) 2 M (80 in) 2 M (80 in)
ST 1 OC 4 GAP 2 ST 1 OC 4 GAP 3	2 M (80 in)
ST 1 OC 4 GAP 3	2 M (80 in)
ST 1 OC 5 GAP 1	2 M (80 in)
ST 1 OC 5 GAP 2 ST 1 OC 5 GAP 3	2 M (80 in)
ST 1 OC 5 GAP 3 ST 1 OC 6 GAP 1	2 M (80 in) 2 M (80 in) 2 M (80 in) 2 M (80 in)
ST 1 OC 6 GAP 1	2 M (80 in)
ST 1 OC 6 GAP 2 ST 1 OC 6 GAP 3	2 M (80 in)
ST 1 OC 6 GAP 3 ST 1 OC 7 GAP 1	2 M (80 in) 2 M (80 in) 2 M (80 in)
ST 1 OC 7 GAP 1	2 M (80 in)
ST 1 OC 7 GAP 2 ST 1 OC 7 GAP 3	2 M (80 in) 2 M (80 in)
	2 M (80 in)
ST 1 OC 8 GAP 1	2 M (80 in)
ST 1 OC 8 GAP 2	2 M (80 in)
st 1 oc 8 gap 3	2 M (80 in)

C	۵	
Cable Label		Length
ST 2 OC 1 GAP 1 &	2	2 M (80 in)
ST 2 OC 1 GAP 3 OC	CT 2 GAP 1	2 M (80 in)
ST 2 OC 2 GAP 2 &	3	2 M (80 in)
ST 2 OC 3 GAP 1 &	2	2 M (80 in)
ST 2 OC 3 GAP 3 OC	CT 4 GAP 1	2 M (80 in)
ST 2 OC 4 GAP 2 &	3	2 M (80 in)
ST 2 OC 5 GAP 1 &	2	2 M (80 in)
ST 2 OC 5 GAP 3 OC	CT 6 GAP 1	2 M (80 in)
ST 2 OC 6 GAP 2 &	3	2 M (80 in)
ST 2 OC 7 GAP 1 &	2	2 M (80 in)
ST 2 OC 7 GAP 3 OC	CT 8 GAP 1	2 M (80 in)
ST 2 OC 8 GAP 2 &	3	2 M (80 in)

Cable Label	Length
ST 3 OC 1 GAP 1 & 3	2 M (80 in)
ST 3 OC 2 GAP 1 & 3	2 M (80 in)
ST 3 OC 3 GAP 1 & 3	2 M (80 in)
ST 3 OC 4 GAP 1 & 3	2 M (80 in)
ST 3 OC 5 GAP 1 & 3	2 M (80 in)
ST 3 OC 6 GAP 1 & 3	2 M (80 in)
ST 3 OC 7 GAP 1 & 3	2 M (80 in)
ST 3 OC 8 GAP 1 & 3	2 M (80 in)

Each cable will have two Labels, one on each end.


Location shown on Sheet 1 Total number of cables = 44

## ASSEMBLY DRAWING

Labels & Cable Lengths

	Los Alamos Nationa	l Laboratory		
Tit le	MUON TRACKING H	HV DIST. SYSTEM		
C	Cable, Distribution Box to H	HV Power Supply		
Size	Date Originated: 31 May 2001			
С	Date Last Revised: 12 June 2001			
LANL DWG # 135Y299083 Approved By: W Sandheim				
PHENIX DW	/G <b>‡</b> : 042-0312-226	Drawn by: G. Hart		
Filename	135Y299083 DB-PS-3.pcb	Sheet 3 of 3		
		-		


## Station 1 North HV Distribution Chamber Inputs Oct 1 Gap 1 Oct 1 Gap 2 Oct 1 Gap 3 Oct 2 Gap 1 Oct 2 Gap 2 Oct 2 Gap 3 Oct 3 Gap 1 Oct 3 Gap 2 Oct 3 Gap 3 Oct 4 Gap 1 Oct 4 Gap 2 Oct 4 Gap 3 Oct 5 Gap 1 Oct 5 Gap 2 Oct 5 Gap 3 Oct 6 Gap 1 Oct 6 Gap 2 Oct 6 Gap 3 Oct 7 Gap 1 Oct 7 Gap 2 Oct 7 Gap 3 Oct 8 Gap 1 Oct 8 Gap 2 Oct 8 Gap 3 LANL 135Y299083 / PHENIX 002-0312-226 Silkscreen in Black Front Panel Silkscreen Los Alamos National Laboratory Front Panel Noth Arm HV Distribution Filename 135Y299083 FP 1.pcb Sheet 2 of 3



Front Side

Front View (Front Side has peel off film)


Paint or anodize front side in Red




Front Panel Fabrication Drawing

	Los Alamos Natio	nal Laboratory	
Title	Front Panel		
	Noth Arm HV Di	stribution	
Size	ize Date Originated: 30 May 2001		
D Date Last Revised: 7 June 2001			
LANL D	NG # 135Y299083	Approved By: W. Sondheim	
PHENIX	DWG #: 002-0312-226	Drawn by: G. Hart	
Filenan	ne 135V200083 ED 1 noh	Charles 4 of 3	

ITEM	QTY	MANUFACTURER	DESCRIPTION	PART #	Source	Cat #	Cost/ea
1	1	Bud Industries	.125" Aluminum Front Panel, Part of NHC-14157 Enclosure	SFA-1834	Newark Electronics	91F268	20.00
2	24	AMP (Div of Tyco)	Block Connector, 20 Pin, HV rated, Female	203909-2	Newark Electronics		12.00
3	48	AMP (Div of Tyco)	Guide Pin, for Type M Connectors (Includes washer & nut)	200833-2	Newark Electronics	50F656	1.00
4	48	AMP (Div of Tyco)	Guide Socket, for Type M Connectors (Includes washer & nut)	200835-2	Newark Electronics	50F657	1.43
5	48	AMP (Div of Tyco)	Jackscrew, Male, Fixed, (Includes washer & nut)	200874-1	Newark Electronics	50F661	.81







#### Front Panel Assembly Drawing

	Los Alamos Nationa	al Laboratory	
Title	Front Panel		
Noth Arm HV Distribution			
Size	Date Originated: 30 May 2001		
D	Date Last Revised: 7 June 2001		
LANL DWG	# 135Y299083	Approved By: W. Sondheim	
PHENIX D	NG #: 002-0312-226	Drawn by: G. Hart	
Filename	135Y299083 FP 1.pcb	Sheet 3 of 3	










Front Side

Rear Panel Fabrication Drawing

	Los Alamos Nationa	al Laboratory
Title	Rear f	Panel
Noth Arm HV [		ribution
Size	Date Originated: 30 May 2001	
D	Date Last Revised: 14 June	2001
LANL DWG	# 135Y299083	Approved By: W. Sondheim
PHENIX DI	VG #: 002-0312-226	Drawn by: G. Hart
Filename	135Y299083 RP 1.pcb	Sheet 1 of 3











#### ST 1 Rear Panel Assembly Drawing

Los Alamos National Laboratory		ial Laboratory
Title	Rear	Panel
	Noth Arm HV Dis	stribution
Size	Date Originated: 30 May 200	21
D	Date Last Revised: 14 June	e 2001
LANL D	NG # 135Y299083	Approved By: W. Sondheim
HENIX	DWG #: 002-0312-226	Drawn by: G. Hart
Filenan	ne 135Y299083 RP 1.pcb	Sheet 3 of 3












135Y299083 Layer 2 (Bottom) 26 June 2001






135Y299083 Layer 1 (Top) Silkscreen 26June 2001



135Y299083 Layer 2 (Bottom) Solder Mask 26 June 2001

Red Color



135Y299083 Layer 1 (Top) Silkscreen 26June 2001

SIGR-HV

Optional Sheild Termination

R16B C7BC


R15B C6B R14B R14B C5B R13B


R12A C3AC R11A C2AC

6

R10A C1A R9A

	Los Alamos National Laboratory	
Title	-	
North Arm HV Dist. System		ist. System
Size	Date Originated: 23 May 2	001
С	Date Last Revised: 26 Ju	ne 2001
LANL DV	/G # 135Y299083	Approved By: W. Sondheim
		Drawn by: G. Hart
		Sheet of 5
		F





## North Arm HVDS Components

#### **Amp Type M Block Connector**

20 HVC Series M Overview

http://catalog.tycoelectronics.com/TE/docs/pdf/1/37/159731.pdf Type III Pin, 66099

http://catalog.tycoelectronics.com/TE/docs/pdf/9/07/162709.pdf Type III Socket, 66101

http://catalog.tycoelectronics.com/TE/docs/pdf/1/17/162711.pdf Type III Pin, 66103

http://catalog.tycoelectronics.com/TE/docs/pdf/3/85/206583.pdf Type III Socket, 66105

http://catalog.tycoelectronics.com/TE/docs/pdf/4/85/206584.pdf Type III Contacts, Application Note

http://catalog.tycoelectronics.com/TE/docs/pdf/0/25/158520.pdf Block connector, 203908

http://catalog.tycoelectronics.com/TE/docs/pdf/4/02/167204.pdf Block connector, 203909

http://catalog.tycoelectronics.com/TE/docs/pdf/5/02/167205.pdf Internal Hood, 202434

http://catalog.tycoelectronics.com/TE/docs/pdf/4/71/167174.pdf Strain Relief, 201224

http://catalog.tycoelectronics.com/TE/docs/pdf/5/80/167085.pdf Jackscrew, fixed stud kit. 200874

http://catalog.tycoelectronics.com/TE/docs/pdf/5/60/167065.pdf Jackscrew, female kit, 200867

http://catalog.tycoelectronics.com/TE/docs/pdf/1/60/167061.pdf Corner guide pin kit, 200833

http://catalog.tycoelectronics.com/TE/docs/pdf/7/41/198147.pdf Corner guide socket kit, 200835

http://catalog.tycoelectronics.com/TE/docs/pdf/8/41/198148.pdf Short shield kit, 200517

http://catalog.tycoelectronics.com/TE/docs/pdf/8/11/186118.pdf

#### **LeCroy 9 Pin Plug Connector**

Type XI socket, 203802

http://catalog.tycoelectronics.com/TE/docs/pdf/7/89/181987.pdf Application sheet, Type XI contacts

http://catalog.tycoelectronics.com/TE/docs/pdf/9/15/158519.pdf Instruction Sheet for type XI hand crimper 90260

http://catalog.tycoelectronics.com/TE/docs/pdf/9/38/206839.pdf

#### Wire / Cable

Belden, 83026 hook-up wire

http://ecom.belden.com/static/ZZBLDNTD01FROMCATA.HTM?P0=83026

Belden, 83030 hook-up wire

http://ecom.belden.com/static/ZZBLDNTD01FROMCATA.HTM?P0=83030

General Wire Products, 11 cond. HV cable data sheet

Page 63

Judd, 5KV hook-up wire

http://www.juddwire.com/jwelcome.nsf/flexrad\_hv.htm

#### Hardware

Bud cabinet

http://www.budind.com/pdf/hb14097.pdf

SPC / Multicomp, 2642 Card guide

http://www.newark.com/product-details/datasheet/spc/92n4857.pdf

Keystone, Male PC Tab terminals

http://www.newark.com/product-details/text/cd119/9192.html

Voltrex, Solderless push-on crimp terminals

http://www.newark.com/product-details/text/cd119/5503.html

#### **Electronic Components**

Sprague, 125LD10 HV Capacitor

http://www.newark.com/product-details/text/cd119/7093.html

SPC / Multicomp½ watt carbon composition resistors

http://www.newark.com/product-details/text/cd119/17346.html

JW Miller, 9250 molded inductor

http://www.newark.com/product-details/text/cd119/7366.html

Ohmite, MOX high value resistor

http://www.ohmite.com/catalog/pdf/v\_minimox.pdf

GC 19-155 Silicone

http://www.newark.com/product-details/text/cd119/7522.html

#### GENERAL WIRE PRODUCTS INC. 425 SHREWBURY STREET WORCHESTER, MA. USA 01604 TEL # 508-753-2173 FAX # 508-753-2173

#### SPECIFICATION ON GWP P/N 001-21919 REVISION B

\_\_\_\_\_\_

DESCRIPTION: THE CABLE OUTLINED HERE SHALL MEET OR EXCEED THE PHYSICAL AND ELECTRICAL PERFORMANCE REQUIREMENTS AS OUTLINED IN CEBAF SPECIFICATION 6620-S-01636. ALL MATERIALS AND METHODS USED IN THE MANUFACTURE AND TEST OF THIS PLENUM RATED PRODUCT SHALL COMPLY WITH UL SUBJECTS 13, 910 AND 1581

GWP P/N 001-21919 REVISION B CONDUCTOR AWG / STRANDING #22 19/34 TINNED COPPER

CONDUCTOR DIAMETER .031"

INSULATION MATERIAL / THICKNESS TEFZEL / .020"

INSULATION DIAMETER .071"

TYPE OF COMPONENT SINGLE CONDUCTOR

NUMBER OF COMPONENTS 1

COLOR CODE BLK, BRN, RED, ORG, YEL, GRN, BLU, VIO,

GRY, WHT, WHT/BLU - BAND MARKED

CABLE FABRICATION 1.6 TWISTS FER FOOT

CABLE DIAMETER .284"

BINDER .002" CLEAR MYLAR

FIRST SHIELD 100% FOIL FREE ALUMINIUM FOIL OUT

SECOND SHIELD 90% TINNED COPPER BRAID

DIAMETER OVER SHIELD .308"

JACKET MATEIAL / THICKNESS TEFZEL / .015"

COLOR: RED FINISHED CABLE DIAMTER .338"

PRINT: "E102914 CL2P 22 AWG 150 C. (UL)"

\_\_\_\_\_\_

MINIMUM ELECTRICAL REQUIREMENTS

SPARK VOLTAGE INLINE 10 KV DC HI-POT 10 KV DC INSULATION RESISTANCE 1.000 VOLTS

-----