




Overview

- i. The Measurement Cell (MCELL) must be flushed to .3% of its value during measurements.
- ii. The Polarization in the MCELL must be at least 99%. In other words, minimize time spent in pipes, minimize surface area to volume ratio in the pipes, while considering heat budget.






Option 2



Maybe 8000cc

Option 2b (not to be?)

•Faster Flush with less heat flux from MCELL to IV2




Whats the difference? The emptying of the Measurement Cells

- The flush from the Measurement Cells into IV2 is more efficient in Option 1 than Option 2.
- Option 2 is less complicated.

Parameter	Option1	7mW			Option2 8	mW		Option 1b	7.	7mW
Total Pipe Length, first part, second part [cm]		450,	25,	425	450	, 110,	, 340	450,	100,	350
First Pipe Radius, Second Pipe Radius [cm]			1.3,	1.85		1.3	1.85		1.3,	1.85
Vmax [cm/sec]				62			63			44
Temp [K]	MCELL: (0.45	V2:	0.432	MCELL 0.4	5 IV2: ().432		.45	.420
time for c < 0.3% [sec] (MCELL and 25 cm of pipe)				294			285		V	249

3D simulation gives better result

3D simulation of MCELL to IV2




Flush from IV1 to MCELL

The 2D model MCELL has less surface area per volume than the 3D model.

This led to .1% decrease in final Polarization. Still within the acceptable range.


Table: IV1 to MCELL 2D and 3D models



Polarization at MCELL entrance 5mW,

Parameter	2D model	A	3D model
Pipe Length [cm]		300	200, 100 Dual
Pipe Radius [cm]		1.3	1.3
Vmax [cm/sec]		44	39
Temp [K]	cell 0.45	IV1: 0.477	cell 0.45 IV1 0.47
Fraction of He3 in MCELL at max polarization	0.76	at 35 seconds	0.79 at 27 seconds
Max Polarization of He3 in MCELL		99.2%	99.1%
Fraction of He3 in MCELL after 75 sec		0.973	0.98
Polarization of He3 in MCELL after 75 sec		99.06%	98.84%

By the way, 4.5 not 3.



4.5m Distance

Assumptions:

- •Probability of depolarization per bounce is 1e-7.
- •MCELL is magically kept at 450mK or 9.9mW of heat can be extracted from MCELL without a terrible Temp. gradient.
- •last 1.7 meters of tube are 'leaky'

Parameter	3D, 450 cm from IV1 to Mcell, 9.9mW flux
Pipe Length [cm]	450
Pipe Radius [cm]	1.3
Vmax [cm/sec]	61
Temp [K]	cell 0.45 IV1: 0.52
Percent of He3 in MCELL at max polarization	60% at 24 seconds
Max Polarization of He3 in MCELL	99.08%

Conclusion.

- •3D simulations do not change the results drastically.
- •4.5m distance from IV1 to MCELL seems possible, yet borderline.

Thank you!